

#### USE AND MAINTENANCE


Use on level surfaces only  
 Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are still tight and working properly  
 Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

## Emery Chesterfield Loveseat


### PART LIST



1 - Loveseat Assembly x1




2 - Loveseat Arm (Seated) Left




3 - Loveseat Arm (Seated) Right



4 - Loveseat Back



5 - Loveseat Front Panel x1




6 - Loveseat Seat x3




7 - Loveseat Leg x4


### Assembly Instructions




Select 4 Loveseat Back×1, 2 Loveseat Arm (Seated) Left and 3 Loveseat Arm (Seated) Right. Insert 2 and 3 into hole in Loveseat Back to hand tighten.




Select 5 Loveseat Front Panel×1, Insert 5 into the 2 and 3.




Put the 6 Loveseat Seat×2 on the 1 Loveseat Assembly to make loveseat comfortable.



Put the 1 Loveseat Assembly on the 5.



Insert 7 legs×4 into the loveseat.



Congratulations! Setup of your new Naomi Home Emery Chesterfield Loveseat is Complete!