


## **USE AND MAINTENANCE**

- Use on level surfaces only
- Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are still tight and working properly for safety.
- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

## **Emery Chesterfield Chair**





3 - Front Rail x1



4 - Rear Rail x1



5 - Seat Support x1



6 - Backrest x1




7 - Seat Cushion x1




**HARDWARE** 



A - Fabric Protector x4





If you need help or have damaged or missing parts, contact customer service at www.NaomiHome.com.



## **USE AND MAINTENANCE**


- Use on level surfaces only
- Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are still tight and working properly for safety.
- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

## **Emery Chesterfield Chair**





5 - Seat Support x1





6 - Backrest x1



7 - Seat Cushion x1

Made in China





is Complete!

Page 2 of 2