

#### USE AND MAINTENANCE


Use on level surfaces only  
 Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are still tight and working properly  
 Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

## Emery Chesterfield Sofa


### PART LIST



1 - Sofa Assembly x1




2 - Sofa Arm (Seated) Left



3 - Sofa Arm (Seated) Right



4 - Sofa Back




5 - Sofa x1



6 - Sofa Seat x3




7 - Sofa Leg x4




8 - Sofa Back Cushion x2


### Assembly Instructions




Select 4 Sofa Back×1, 2 Sofa Arm (Seated) Left and 3 Sofa Arm (Seated) Right. Insert 2 and 3 into hole in Sofa Back to hand tighten.




Select 5 Sofa Front Panel×1, Insert 5 into the 2 and 3.




Put the 1 Sofa Assembly on the 5.



Put the 6 Sofa Seat×3 on the 1 Sofa Assembly to make sofa comfortable.



Put the 8 Sofa Back Cushion×2 on the sofa, and insert 7 leg×4 into the sofa.



Congratulations! Setup of your new Naomi Home Emery Chesterfield Sofa is Complete!