




N A O M I  
K I D S

# Gourmet Kitchen



## WARNING ! CAUTION

- ADULT ASSEMBLY REQUIRED.
- CHOKING HAZARD. This product includes small parts, sharp points and sharp edges in its unassembled state. Keep unassembled parts away from children under 3 years of age.
- If used improperly, your kitchen may be pulled over or fall, creating risk of injury or damage. Children should not be permitted to climb or pull on the kitchen.

### USE AND MAINTENANCE:

- Use on level surfaces only!
- Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are still tight and working properly for the safety and enjoyment of your child.

### PARENTAL SUPERVISION IS REQUIRED.

- This Naomi Kids product is intended for a specific age or older.
- Parents or Guardians should supervise the play area in case younger children have access to it and might climb on it.
- See instructions included with the wall strap.



--- A Message from Naomi Kids ---

Dear Parents and Dealers,

Thank you for choosing the Naomi Kids kitchen for continued entertainment and enlightenment of your growing child. At Naomi Kids we take great pride in our products, and as parents ourselves we recognize that safety and quality are our highest priorities. As new safety regulations arise, Naomi Kids has taken every precaution to ensure that our products remain compliant with changing laws and policies.

The Naomi Kids testing program ensures that the products meet or exceed all federal and CPSIA requirements, including mechanical hazards, lead and other heavy metals, phthalate and flammability. All product testing is performed by third-party certified labs to verify that they meet or exceed all applicable U.S. regulatory safety standards.

Most recently, Naomi Kids reviewed and confirmed compliance with the Illinois Lead Poisoning Prevention Act, which sets lead limits on any children's product being sold in the state.

The California Air Resources Board (CARB) ACTM 93120 requirement is a multi-step regulation that limits formaldehyde emissions in composite wood products being sold into California. CARB is currently in Phase 2, which is the last phase of the act, and Naomi Kids products remain compliant.

Naomi Kids is committed to you and the safety of your children while delivering high quality products that will last. You can trust in Naomi Kids testing program to keep your growing child's mind and body safe from harm when you select a Naomi Kids product.

Thank you for your continued support.


Sincerely,

Naomi Kids Product Safety Team

# ASSEMBLY AT A GLANCE


Please take a moment to read through the whole instruction booklet before assembly to familiarize yourself with this product. Once you feel ready to start, follow the instructions step by step and this should make this process as easy as we could make it for you.

Due to the number of parts involved, assembly can take a few hours so set aside between 2 and 3 hours to assemble this without rushing.




This drawing is to give you an overall idea only of how this assembly will go together and does not replace the assembly instructions.


# COMPONENT PARTS




**1** Right Panel (x1)




**2** Middle Panel 1 (x1)




**3** Middle Panel 2 (x1)




**4** Left Panel (x1)



**5** Bottom Panel (x1)



**6** Toe Kick (x1)




**7** Dishwasher Rack (x1)




**8** Dishwasher Control Panel (x1)



**9** Stove Control Panel (x1)




**10** Top Valance (x1)




**11** Fridge Shelves (x2)




**12** Backsplash behind Stove (x1)




**13** Backsplash behind Sink (x1)



**14** Backwall behind Dishwasher and Oven (x2)




**15** Backwall Fridge (x1)




**16** Counter Top (1) & Burners (x4)



**17** Oven Door (x1)




**18** Dishwasher Door (x1)



**19** Freezer Door (x1)



**20** Fridge Door (x1)




**21** Microwave Door (x1)



**22** Microwave Control Panel (x1)



**23** Microwave Left Support (x1)




**24** Shelf (x1)




**25** Microwave Bottom (x1)



**26** Microwave Right Support (x1)



**27** Top Panel (x1)



**28** Oven Rack (x1)



**29** Towel Rack Supports (x2)



**30** Glider Spacer (x2)



**31** Towel Rack (x1)




**32** Towel Knob (x1)



**K** Plastic Gliders (x4)



**L** Faucet (x1)



**M** Sink (x1)




**O** Door Handles (x5)

\*See Next Page for Additional Hardware

For ease of identification, Components have been marked with a removable sticker showing their assigned number in these instructions.


# ASSEMBLY HARDWARE



Note : Use a Phillips Screw-Driver for assembly (not included).




Please check to see if you have all the parts and components listed here. If you are missing any parts please STOP and contact customer service. Visit [www.NaomiHome.com](http://www.NaomiHome.com)

**WALL STRAP BRACKET KIT**  
For details on this kit, please go to page 19 for more info.






## INSTALLING CAM LOCKS



- 1** Identify arrow on head. Look closely.
- 2** Arrow MUST point toward hole in edge of panel.
- 3** Push cam lock all the way down into hole.




## INSTALLING CAM BOLTS




# PRE-ASSEMBLY PREP - HARDWARE ASSEMBLY



# PRE-ASSEMBLY PREP - HARDWARE ASSEMBLY




# PRE-ASSEMBLY PREP - HARDWARE ASSEMBLY






## PRE-ASSEMBLY PREP - HARDWARE ASSEMBLY




Please Note : Double check to make sure all the burners line up the same way.

## ASSEMBLY INSTRUCTIONS




# ASSEMBLY INSTRUCTIONS


5



6





7




# ASSEMBLY INSTRUCTIONS

8




Please note: After Step 8 is completed, please carefully lift up the unit from the top end so that it stands upright for Step 9. Make sure the area is clear so the unit stands flatly on the floor. Then proceed to Step 9.

9




# ASSEMBLY INSTRUCTIONS

10




11




Screw panel 23 into panel 25 first. Add Shelf 24 next and then attach Panel 26.

# ASSEMBLY INSTRUCTIONS

12




13



# ASSEMBLY INSTRUCTIONS


14

Place the wood dowels into the holes in the microwave side before installing the bolts in the step below .



Note the drill hole at the top of part 15.


15






# ASSEMBLY INSTRUCTIONS

16



17










# ASSEMBLY INSTRUCTIONS

18

Insert Spacer 30 with I between the panel 2 and the plastic glider. Align drill holes and insert screw D. Repeat for panel 4 glider. No spacer needed on panel 3 gliders.




19




# ASSEMBLY INSTRUCTIONS


20



Hinge Attachment (x8)



21




# WALL STRAP BRACKET KIT

**WARNING:** The wall strap kit is only a deterrent, and it is not a substitute for proper adult supervision. For safe use of this kitchen we recommend that you secure it to the wall with the wall strap bracket kit included.

1. Attach one of the mounting brackets securely to the back edge of the top panel part 27. Install bracket to top of the unit. Use the shorter screw.
2. Determine where furniture is to be placed and mark location on the wall for the mounting bracket screw hole approximately 2" below the bracket mounted to the top panel 27 on the kitchen.
3. Drill a 3/8" hole in the wall. Press the plastic anchor into the hole and gently tap with a light hammer until the flange on the anchor is against the wall surface.
4. Position the bracket over the anchor and use the longer screw to securely attach the bracket to the wall.
5. Place the furniture so the bracket on the back edge is in line with the bracket on the wall.
6. Lace an end of the nylon restraint strap down through each bracket. Bring both ends together and slide the beaded end of the strap through the keyhole shaped slot in the other end until snug. Pull down on the beaded end until it snap locks into the keyhole slot.
7. To double lock return the beaded end backthrough the keyhole as shown.
8. Check to make sure the strap is securely laced and locked to the brackets.


Please note: If anchoring into plaster, brick or other harder surfaces , you may wish to consult with your local hardware store for the appropriate anchor and type of drillbit .

## ASSEMBLY HARDWARE




## ASSEMBLY INSTRUCTIONS

TO ATTACH TO THE BACK OF THE KITCHEN




TO ATTACH TO THE WALL

9.5mm 3/8" hole in wall



# COMPLETED GOURMET KITCHEN



[www.NaomiHome.com](http://www.NaomiHome.com)  
MADE IN CHINA

## Product Packaging Information

Shipment info sticker goes here.