


USE AND MAINTENANCE

- Use on level surfaces only
- Because this product needs assembly, it is prone to working itself loose from time to time depending on the use. Please take the time to check that all connections are still tight and working properly for safety.
- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

Kids On the Rise Stool

PART LIST



HARDWARE



A - Screw x16



B - Wood Dowel x14

Assembly Instructions

